PCAN-PCI

CAN Interface for PCI

User Manual



Document version 2.4.0 (2015-06-09)

Products taken into account

Product Name	Model	Part Number
PCAN-PCI Single Channel	One CAN channel	IPEH-002064
PCAN-PCI Dual Channel	Two CAN channels	IPEH-002065
PCAN-PCI Single Channel opto-decoupled	One CAN channel, galvanic isolation for CAN connection	IPEH-002066
PCAN-PCI Dual Channel opto-decoupled	Two CAN channels, galvanic isolation for CAN connections	IPEH-002067

The cover picture shows the product PCAN-PCI Dual Channel opto-decoupled. Other product versions have an identical form factor but vary in equipment.

CANopen® and CiA® are registered community trade marks of CAN in Automation e.v.

All other product names mentioned in this manual may be the trademarks or registered trademarks of their respective companies. They are not explicitly marked by "™" and "®".

Copyright © 2015 PEAK-System Technik GmbH
Duplication (copying, printing, or other forms) and the electronic distribution of this document is only allowed with explicit permission of PEAK-System Technik GmbH. PEAK-System Technik GmbH reserves the right to change technical data without prior announcement. The general business conditions and the regulations of the license agreement apply. All rights are reserved.

PEAK-System Technik GmbH
Otto-Roehm-Strasse 69
64293 Darmstadt
Germany

Phone: +49 (0)6151 8173-20
Fax: +49 (0)6151 8173-29

www.peak-system.com
info@peak-system.com

Document version 2.4.0 (2015-06-09)

Contents

1 Introduction 5

1.1 Properties at a Glance 5

1.2 System Requirements 6

1.3 Scope of Supply 6

2 Installing the Software and the Card 7

3 Connecting the CAN Bus 10

3.1 D-Sub Connector 10

3.2 Supplying External Devices via the CAN Connector 11

3.3 Cabling 13

3.3.1 Termination 13

3.3.2 Example of a Connection 13

3.3.3 Maximum Bus Length 14

4 Software and API 15

4.1 Monitor Software PCAN-View 15

4.1.1 Receive/Transmit Tab 18

4.1.2 Trace Tab 20

4.1.3 PCAN-PCI Tab 21

4.1.4 Status Bar 21

4.2 Linking Own Programs with PCAN-Basic 22

4.2.1 Features of PCAN-Basic 23

4.2.2 Principle Description of the API 24

4.2.3 Notes about the License 25

5 Technical Specifications 26

Appendix A CE Certificate 28

Appendix B Dimension Drawing 29

Appendix C Quick Reference 30

1 Introduction

The PCAN-PCI card enables the connection of a PC with PCI slots to CAN networks. The card is available as a single or dual-channel version. The opto-decoupled versions also guarantee galvanic isolation of up to 500 Volts between the PC and the CAN sides. Device drivers and programming interfaces exist for different operating systems, so programs can easily access a connected CAN bus.

Tip: At the end of this manual (Appendix C) you can find a Quick Reference with brief information about the installation and operation of the PCAN-PCI card.

1.1 Properties at a Glance

- PC plug-in card for PCI slot
- 1 or 2 High-speed CAN channels (ISO 11898-2)
- Bit rates from 5 kbit/s up to 1 Mbit/s
- Compliant with CAN specifications 2.0A (11-bit ID) and 2.0B (29-bit ID)
- CAN bus connection via D-Sub, 9-pin (in accordance with CiA® 102)
- NXP SJA1000 CAN controller, 16 MHz clock frequency
- NXP PCA82C251 CAN transceiver
- Galvanic isolation on the CAN connection up to 500 V (only opto-decoupled versions), separate for each CAN channel
- 5-Volt supply to the CAN connection can be connected through a solder jumper, e.g. for external bus converter

- Extended operating temperature range from -40 to 85 °C (-40 to 185 °F)

Note: This manual describes the use of the PCAN-PCI card with **Windows**. You can find device drivers for **Linux** and the corresponding application information on the provided DVD in the directory branch `Develop` and on our website under www.peak-system.com/linux.

1.2 System Requirements

- A vacant PCI slot in the computer
- Operating system Windows 8.1, 7, Vista (32/64-bit) or Windows CE 6.x (x86 and ARMv4 processor support) or Linux (32/64-bit)

1.3 Scope of Supply

- PCAN-PCI card
- Device drivers for Windows 8.1, 7, Vista and Linux (32/64-bit)
- Device driver for Windows CE 6.x (x86 and ARMv4 processor support)
- PCAN-View CAN monitor for Windows 8.1, 7, Vista (32/64-bit)
- PCAN-Basic programming interface consisting of an interface DLL, examples, and header files for all common programming languages
- Manual in PDF format

2 Installing the Software and the Card

This chapter covers the software setup for the PCAN-PCI card under Windows and the installation of the card in the computer.

Setup the driver before installing the PCAN-PCI card.

- Do the following to install the driver:

1. Insert the supplied DVD into the appropriate drive of the computer. Usually a navigation program appears a few moments later. If not, start the file `Intro.exe` from the root directory of the DVD.
2. In the main menu, select **Drivers**, and then click on **Install now**.
3. Confirm the message of the User Account Control regarding the "Installer Database of PEAK Drivers".

   The setup program for the driver is started.
4. Follow the instructions of the program.

Do the following to install the PCAN-PCI card in the computer:

Attention! Electrostatic discharge (ESD) can damage or destroy components on the PCAN-PCI card. Take precautions to avoid ESD when handling the card.



Figure 1: Position of the CAN connectors CAN 1 (lower position) and CAN 2 (upper position). In the Single Channel version, CAN 1 remains at the same position

1. Shut down the computer.
2. Disconnect the computer from the power supply.
3. Open the computer's casing.
4. Insert the PCAN-PCI card into an empty PCI slot. For details please refer to the documentation of the computer.
5. Close the computer's casing.
6. Reconnect the power supply of the computer.

Do the following to complete the initialization:

1. Turn on the computer and start Windows. Make sure that you are logged in as user with administrator privileges.

   Windows notifies that new hardware has been detected. The drivers are found and installed by Windows.

After the initialization process is finished successfully, you can find the entry “PCAN-PCI” in the branch “CAN-Hardware” of the Windows Device Manager.

3 Connecting the CAN Bus

3.1 D-Sub Connector

A High-speed CAN bus (ISO 11898-2) is connected to the 9-pin D-Sub connector. The pin assignment for CAN corresponds to the specification CiA® 102.



Figure 2: Pin assignment of High-speed CAN connection
(view onto a male connector on the PCAN-PCI card)

With the pins 1 and 9 devices with low power consumption (e.g. bus converters) can be directly supplied via the CAN connector. At delivery these pins are not assigned. You can find a detailed description in the following section 3.2.

Tip: You can connect a CAN bus with a different transmission standard via a bus converter. PEAK-System offers different bus converter modules (e.g. PCAN-TJA1054 for a Low-speed CAN bus according to ISO 11898-3).

3.2 Supplying External Devices via the CAN Connector

A 5-Volt supply can optionally be routed to pin 1 and/or pin 9 of a D-Sub connector by setting solder bridges on the PCAN-PCI card (independently for each connector on the Dual Channel versions). Thus devices with low power consumption (e.g. bus converters) can be directly supplied via the CAN connector.

When using this option the 5-Volt supply is connected to the power supply of the computer and is not fused separately. The opto-decoupled versions of the card contain an interconnected DC/DC converter. Therefore the current output is limited to about 50 mA.

➡ Proceed as follows to activate the 5-Volt supply:

Attention! Electrostatic discharge (ESD) can damage or destroy components on the PCAN-PCI card. Take precautions to avoid ESD when handling the card.

Set the solder bridge(s) on the PCAN-PCI card according to the desired settings. During this procedure take especially care not to produce unwanted short circuits on the card.

Figure 3 shows the positions of the solder fields on the PCAN-PCI card. The table below contains the possible settings.



Figure 3: PCAN-PCI card, LJ21 (lower marker) and LJ22 (upper marker)

5-Volt supply →	None	Pin 1	Pin 9	Pin 1 + Pin 9
LJ21 (CAN channel 1) / LJ22 (CAN channel 2)				

Attention! Risk of short circuit! If the option described in this section is activated, you may only connect or disconnect CAN cables or peripheral systems (e.g. bus converters) to or from the PCAN-PCI card while the computer is de-energized.

3.3 Cabling

3.3.1 Termination

A High-speed CAN bus (ISO 11898-2) must be terminated on both ends with 120 Ohms. Otherwise, there are interfering signal reflections and the transceivers of the connected CAN nodes (CAN-interface, control device) will not work.

The PCAN-PCI card does not have an internal termination. Use the card on a terminated CAN bus.

3.3.2 Example of a Connection



Figure 4: Simple CAN connection

In this example, the PCAN-PCI card is connected with a control unit by a cable that is terminated at both ends.

3.3.3 Maximum Bus Length

High-Speed-CAN networks may have bit rates of up to 1 Mbit/s. The maximum bus length depends primarily on the bit rate.

The following table shows the maximum possible CAN bus length at different bit rates:

Bit rate	Bus length
1 Mbit/s	40 m
500 kbit/s	110 m
250 kbit/s	240 m
125 kbit/s	500 m
50 kbit/s	1.3 km
20 kbit/s	3.3 km
10 kbit/s	6.6 km
5 kbit/s	13.0 km

The listed values have been calculated on the basis of an idealized system and can differ from reality.

4 Software and API

This chapter covers the provided software PCAN-View and the programming interface PCAN-Basic.

4.1 Monitor Software PCAN-View

PCAN-View is simple Windows software for viewing, transmitting, and logging CAN- and CAN FD messages.

Note: This chapter describes the use of PCAN-View with a CAN adapter.



Figure 5: PCAN-View for Windows

Do the following to start and initialize PCAN-View:

1. Open the Windows Start menu or the Windows Start page and select **PCAN-View**.

   The dialog box for selecting the hardware and for setting the parameters appears.



Figure 6: Selection of the specific hardware and parameters

2. From the list **Available PCAN hardware,** select the desired interface to be used.
3. Select the bit rate that is used by all nodes on the CAN bus from the drop-down list **Bit rate**. Use the button to the right of the drop-down list to create User-defined bit rates.
4. Under **Filter settings** you can limit the range of CAN IDs to be received, either for standard frames (11-bit IDs) or for extended frames (29-bit IDs).

5. Activate the **Listen-only mode** if you do not actively participate in the CAN traffic and just want to observe. This also avoids an unintended disruption of an unknown CAN environment (e.g. due to different bit rates).
6. Finally, confirm the settings in the dialog box with **OK**. The main window of PCAN-View appears (see Figure 7).

4.1.1 Receive/Transmit Tab


PCAN-View
File CAN Edit Transmit View Trace Help
Receive / Transmit
Trace
PCAN-USB
CAN-ID Type Length Data Cycle Time Count
255h 8 66 67 6D 68 68 6A 2C 2C 149,9 69
240h 4 66 67 7A 68 100,0 100
201h 5 73 6C 62 45 6D 499,9 21
250h 6 6D 68 68 67 64 6D 3695,8 3
Receive
CAN-ID Type Length Data Cycle Time Count Trigger Comment
150h 6 6D 68 68 67 64 6D Wait 7 Manual
Transmit
Connected to hardware PCAN-USB (500 kBit/s)
Status: OK
Overruns: 0
QXmtFull: 0

Figure 7: Receive/Transmit tab

The Receive/Transmit tab is the main element of PCAN-View. It contains two lists, one for received messages and one for the transmit messages. Representation of CAN data is in hexadecimal format.

Do the following to transmit a CAN message with PCAN-View:

1. Select the menu command **Transmit** > **New Message** (alternatively or Ins).

   The dialog box **New Transmit Message** is shown.



Figure 8: Dialog box new transmit message

2. Enter the ID and the data for the new CAN message.
3. The field **Cycle Time** indicates if the message shall be transmitted manually or periodically. If you want to transmit the message periodically, you must enter a value greater than 0. For a manual-only transmission enter 0.
4. Confirm the entries with **OK**.

   The created transmit message appears on the **Receive/Transmit** tab.
5. You trigger selected transmit messages manually with the menu command **Transmit** > **Send** (alternatively Space bar). The manual transmission for CAN messages being transmitted periodically is carried out additionally.

Tip: Using the menu command **File** > **Save** the current transmit messages can be saved to a list and loaded for reuse later on.

4.1.2 Trace Tab



Figure 9: Trace tab

On the Trace tab the data tracer of PCAN-View is used for logging the communication on a CAN bus. During this process the CAN messages are cached in the working memory of the PC. Afterwards they can be saved to a file.

The tracer can be configured to run in linear or in ring buffer mode. In linear buffer mode the logging is stopped as soon as the buffer is filled completely. In ring buffer mode the oldest messages are overwritten by incoming ones.

4.1.3 PCAN-PCI Tab



Figure 10: PCAN-PCI tab

On the PCAN-PCI tab various information about your hardware is displayed, like the current device driver version.

4.1.4 Status Bar

Figure 11: Display of the status Bar

The status bar shows information about the current CAN connection, about error counters (Overruns, QXmtFull) and shows error messages.

You can find further information about the use of PCAN-View in the help which you can invoke in the program via the menu **Help** or the F1 key.

4.2 Linking Own Programs with PCAN-Basic



Figure 12: PCAN-Basic

On the provided DVD you can find files of the programming interface PCAN-Basic in the directory branch `Develop`. This API provides basic functions for linking own programs to CAN- and CAN FD interfaces by PEAK-System and can be used for the following operating systems:

- Windows 8.1, 7, Vista (32/64-bit)
- Windows CE 6.x (x86/ARMv4)
- Linux (32/64-bit)

The API is designed for cross-platform use. Therefore software projects can easily ported between platforms with low efforts. For all common programming languages examples are available.

Beginning with version 4, PCAN-Basic supports the new CAN FD standard (CAN with Flexible Data Rate) which is primarily characterized by higher bandwidth for data transfer.

4.2.1 Features of PCAN-Basic

- API for developing applications with CAN and CAN FD connection
- Access to the CAN channels of a PCAN-Gateway via the new PCAN-LAN device type
- Supports the operating systems Windows 8.1, 7, Vista (32/64-bit), Windows CE 6.x, and Linux (32/64-bit)
- Multiple PEAK-System applications and your own can be operated on a physical channel at the same time
- Use of a single DLL for all supported hardware types
- Use of up to 16 channels for each hardware unit (depending on the PEAK CAN interface used)
- Simple switching between the channels of a PEAK CAN interface
- Driver-internal buffer for 32,768 messages per CAN channel
- Precision of time stamps on received messages up to 1 µs (depending on the PEAK CAN interface used)
- Supports PEAK-System's trace formats version 1.1 and 2.0 (for CAN-FD applications)
- Access to specific hardware parameters, such as listen-only mode
- Notification of the application through Windows events when a message is received
- Extended system for debugging operations
- Multilingual debugging output
- Output language depends on operating system
- Debugging information can be defined individually

An overview of the API functions is located in the header files. You can find detailed information about the PCAN-Basic API on the provided DVD in the text and help files (file name extensions `.txt` and `.chm`).

4.2.2 Principle Description of the API

The PCAN-Basic API is the interface between the user application and device driver. In Windows operating systems this is a DLL (Dynamic Link Library).

The sequence of accessing the CAN interface is divided into three phases:

1. Initialization
2. Interaction
3. Completion

Initialization

A channel must be initialized before using it. This is done by the simple call of the function `CAN_Initialize` for CAN and `CAN_InitializeFD` for CAN-FD. Depending on the type of the CAN hardware, up to 16 CAN channels can be opened at the same time. After a successful initialization the CAN channel is ready for communication with the CAN hardware and the CAN bus. No further configuration steps are required.

Interaction

For receiving and transmitting messages the functions `CAN_Read` and `CAN_Write` as well as `CAN_ReadFD` and `CAN_WriteFD` are available. Additional settings can be made, e.g. setting up message filters to confine to specific CAN IDs or setting the CAN controller to listen-only mode.

When receiving CAN messages, events are used for an automatic notification of an application (client). This offers the following advantages:

- The application no longer needs to check for received messages periodically (no polling).
- The response time at reception is reduced.

Completion

To end the communication the function `CAN_Uninitialize` is called in order to release the reserved resources for the CAN channel, among others. In addition the CAN channel is marked as "Free" and is available to other applications.

4.2.3 Notes about the License

Device drivers, the interface DLL, and further files needed for linking are property of the PEAK-System Technik GmbH and may be used only in connection with a hardware component purchased from PEAK-System or one of its partners. If a CAN hardware component of third-party suppliers should be compatible to one of PEAK-System, then you are not allowed to use or to pass on the driver software of PEAK-System.

If a third-party supplier develops software based on the PCAN-Basic and problems occur during the use of this software, consult the software provider.

5 Technical Specifications

Connectors	
Computer	PCI bus (Rev. 2.2), PC98, 32-bit bus width, for 3.3 V and 5 V systems
CAN	D-Sub (m), 9 pins Pin assignment according to specification CiA® 102

CAN	
Specification	ISO 11898-2, High-speed CAN 2.0A (standard format) and 2.0B (extended format)
Bit rates	5 kbit/s - 1 Mbit/s
Controller	NXP SJA1000
Transceiver	NXP PCA82C251
Galvanic isolation	PCAN-PCI: none PCAN-PCI opto: up to 500 V, separate for each Channel
Supplying external devices	PCAN-PCI: D-Sub pin 1 /pin 9; 5 V, max. 100 mA PCAN-PCI opto: D-Sub pin 1 /pin 9; 5 V, max. 50 mA Not assigned at delivery
Termination	none

Supply		
Supply voltage	3.3 V - 5 V	
Current consumption	PCAN-PCI Single Channel: PCAN-PCI Dual Channel: PCAN-PCI Single Ch. opto: PCAN-PCI Dual Ch. opto:	max. 150 mA max. 280 mA max. 260 mA max. 490 mA

Measures		
Size	PCB: 93 x 120 mm See also dimension drawing in Appendix B on page 29	
Weight	PCAN-PCI Single Channel: PCAN-PCI Dual Channel: PCAN-PCI Single Ch. opto: PCAN-PCI Dual Ch. opto:	54 g 63 g 55 g 65 g

Continued on the next page

Environment	
Operating temperature	-40 - 85 °C (-40 - 185 °F)
Temperature for storage and transport	-40 - 125 °C (-40 - 257 °F)
Relative humidity	15 - 90 %, not condensing
EMC	EN 55024:2011-09 EN 55022:2011-12 EC directive 2004/108/EG

Appendix A CE Certificate

PCAN-PCI IPEH-002064/65/66/67 – EC Declaration of Conformity
PEAK-System Technik GmbH

Notes on the CE Symbol CE

The following applies to the "PCAN-PCI" product with the item number(s) IPEH-002064/65/66/67.

EC Directive This product fulfills the requirements of EU EMC Directive 2004/108/EG (Electromagnetic Compatibility) and is designed for the following fields of application as for the CE marking:

Electromagnetic Immunity
DIN EN 55024, publication date 2011-09
Information technology equipment – Immunity characteristics – Limits and methods of measurement (CISPR 24:2010);
German version EN 55024:2010

Electromagnetic Emission
DIN EN 55022, publication date 2011-12
Information technology equipment – Radio disturbance characteristics – Limits and methods of measurement (CISPR 22:2008, modified);
German version EN 55022:2010

Declarations of Conformity In accordance with the above mentioned EU directives, the EC declarations of conformity and the associated documentation are held at the disposal of the competent authorities at the address below:

PEAK-System Technik GmbH
Mr. Wilhelm
Otto-Roehm-Strasse 69
64293 Darmstadt
Germany

Phone: +49 (0)6151 8173-20
Fax: +49 (0)6151 8173-29
E-mail: info@peak-system.com

Signed this 22nd day of October 2013

Appendix B Dimension Drawing



Figure 13: Dimension drawing PCAN-PCI

The figure doesn't show the actual size of the product.

Appendix C Quick Reference

Software/Hardware Installation under Windows

Before installing the PCAN-PCI card into the computer set up the corresponding software package from the supplied DVD (with administrator privileges). Afterwards, insert the PCAN-PCI card into a vacant PCI slot of the switched off computer. The PCAN-PCI card is recognized by Windows and the driver is initialized. After the installation process is finished successfully you can find the entry "PCAN-PCI" in the branch "CAN-Hardware" of the Windows Device Manager.

Getting Started under Windows

Run the CAN monitor PCAN-View from the Windows Start menu as a sample application for accessing the PCAN-PCI card. For initialization of the PCAN-PCI card select the desired CAN channel and the CAN bit rate.

High-speed CAN connector (D-Sub, 9 pins)